

• READ FIRST

THIS MANUAL CONTAINS IMPORTANT PRODUCT
AND SAFETY INFORMATION

WELCOME TO YOUR NEW IBIZA BOUNCE PLATFORM!

Your NEW Ibiza Bounce Platform represents the very best quality, craftmanship and technical innovation in the industry. With proper care your bounce platform will give you years of enjoyment.

TABLE OF CONTENTS

INTRODUCTION AND SAFETY	3
WARRANTY	3
SAFETY	4
ASSEMBLYINSTRUCTIONS	6
STORAGE AND CLEANING	9
REPAIRS	10
DISCLAIMER	11
TEDMS OF HISE	11

PACKAGE CONTENTS

- 1 Inflatable Tube
- 1 Boarding Ladder
- 1 Electric Air Pump
- 1 Repair Kit

WARNING

Any person using a water trampoline built and/or sold by AKONA is personally responsible for determining that their abilities are equal or superior to the conditions encountered and can exercise proper judgment in choice of where and when to use. Any person using an AKONA Ibiza Bounce Platform assumes all risks and takes complete responsibility for any and all damages, or injuries including death, which may result from use of, or participation in AKONA Ibiza Bounce Platform. The user of this product should understand that participating in water activities may involve serious injury or death. Observe the following safety standards whenever using this product.

INTRODUCTION AND SAFETY

The Owner's Manual is presented to enhance your enjoyment of the sport. It is intended to alert you to some of the potentially dangerous conditions that can arise in all water sports. Please take a few minutes to read this manual before assembling and using the product. Although the product is simple to use, this manual contains important safety information that you and all users must understand to safely enjoy the Ibiza Bounce Platform.

IT IS THE OWNER'S RESPONSIBILITY

to read the owner's manual and instruct all users in the safe operation of these products. By using these products, you agree to the Terms and Conditions, Disclaimer and Warnings in this manual. Please read this manual prior to using these products and keep for future reference. As with any action sport, recklessness, inexperience, misuse or neglect of the equipment may result in serious injury or death.

LIMITED WARRANTY

We aim to provide our customers with high quality watersports equipment, but sometimes the unexpected happens. All AKONA Water Trampoline products are provided with one year warranty on parts and manufacturer defects and a two year hull warranty. This excludes damage due to misuse, improper care, handling impact damage and light abrasions.

HOW TO OBTAIN WARRANTY

To obtain repair or replacement, call AKONA customer service at 1.800.774.447

or email AKONA at: recgroup@diversco.com

In the event of warranty claim, on initial contact, please attach the product name, your full name, address, phone number, brief description of the problem and proof of purchase date.

SAFETY RECOMMENDATIONS

- Read and understand all of the information contained in this owner's manual before assembling and using your product.
- Make sure that everyone who uses the product is provided with and understands these safety rules and information.
- The Ibiza is designed to be used only in large bodies of water with depths of at least 9 feet (2,4m) of water. Do not use or allow anyone else to use the product on land or any other hard surface or in swimming pools or shallow water.
- Choose a location for your product that is most protected from wind, of sufficient water depth, and free of obstructions.
- Always anchor the Ibiza securely before it is used on water.
- Always wear a U.S. Coast Guard approved Type III (PFD) vest when using the products.
- Never use the product under the influence of alcohol or drugs.
- Always stay under control while using the product.
- Always use in ideal conditions and when there is no risk of injury due to bad weather or water conditions.
- Never dive off of the Ibiza head first. If you choose to jump off the product, always enter the water feet first.
- Never swim or play under or around the Ibiza
- Never use the product while tired or fatigued. Use extreme caution while swimming between the shore and the product. Do not attempt to swim this distance if you are tired or fatigued.
- In familiar and unfamiliar waters, always ensure the areas around and under the product are free of all rocks, logs, sand bars, and underwater obstructions and that the product is at a safe distance from hard objects and placed in water that is the recommend depth.
- When not in use, secure the product against unauthorized or unsupervised use by removing the Ibiza from the water.
- Never use the Ibiza unless the safety pad is in place and securely fastened to the trampoline frame.
- Always inspect your product for any worn, defective, or missing parts.

SAFETY RECOMMENDATIONS

- Flips, somersaults or other acrobatic maneuvers should never be performed on the Ibiza as it could cause long term injury or death. Use only under adult supervision.
- Not recommended for children younger than six years of age.
- DO NOT OVER-INFLATE. This could cause seam rupture.
- Do not use in shark invested water or in water that may contain other marine life dangerous to humans, this could harm marine life and/or cause damage to the product.
- Ensure proper air pressure is maintained while the product is in use. Change in temperature can cause air pressure to increase/decrease.
- This product is not designed to be used as a life saving device.
- Take off any jewelry and any other sharp objects before use, failing to do so can damage the product.

WARNING!

- Misuse and abuse of the Ibiza is dangerous and can cause serious injuries including broken bones, cuts, nerve damage, spinal cord and brain injury, or death.
- Trampolines, being rebound devices, propel the performer to unaccustomed heights and into a variety of body movements.
- All purchasers and all persons using the Ibiza must become familiar with the
 manufacturer's recommendations for proper assembly, use and care of the
 trampoline, as well as being alert to the performer's own limitations in the
 execution of trampoline skills. Assembly instruction, selected precautions,
 recommended instructional techniques and progressions are included to
 promote safe, enjoyable use of the equipment.
- Safety pads must be used at all times. The pads are designed to prevent injury due to falling upon the outer frame or on the springs.
- Secure the Ibiza against unauthorized and unsupervised use by disconnecting the ladder and removing it from the water.

OWNER'S MANUAL

Product	Minimum Water	Maximum	Maximum	Working
	Depth	Capacity	Weight	Pressure
Ibiza	9ft (2,4m)	4 Users	700lbs (317kg)	2 psi (0,14 bar)



ASSEMBLY INSTRUCTIONS

UNPACK THE CONTENTS

1 Lay the Ibiza on a flat clean surface. Make sure there are no sharp objects under the product that might puncture the tube or damage the product.

INFLATE THE TUBE

- 2 Locate the valve of the Ibiza and unscrew the cap. We recommend using the High Speed Inflater/Deflater from AKONA to inflate and deflate.
- To lock open valve, depress stem and rotate ¼ turn clockwise. To close valve, depress stem and rotate ¼ turn counter-clockwise. The valve stem should be in the depressed position while inflating. Replace cap on valve after inflation to ensure air tight seal.

ASSEMBLY INSTRUCTIONS

NOTE:

A special inflation adapter is included with this product. If you are using the AKONA Sports High Speed Inflator, simply lock the adapter onto the end of the inflation hose and insert into the valve body.

4 Turn ¼ turn to lock in place.

ATTENTION: This inflation adaptor will automatically open the valve when inserted and will close the valve when removed. You do not need to manually open/close the valve when using this special adaptor.

Inflate until the tube is firm and resistant to pressure. Your hand should create minimal depression when pushed against the tube. Replace cap to ensure an air tight seal.

CAUTION!

DO NOT OVER-INFLATE.

Do not exceed 2.5 PSI (0,17 bar) if filling with compressed air. Excessive pressure can cause the tube to rupture with potentially damaging force to eyes, ears, skin and limbs. Use of an air compressor over-inflation can rupture the tube beyond repair, thus voiding the warranty.

Air pressure within the tube can fluctuate depending on air and water temperatures. It may be necessary to increase or decrease the air pressure in your product accordingly. To avoid damage on extremely hot days it maybe necessary to check and release the air pressure from your product throughout the day. A fully inflated product on warm land will lose some of its pressure when placed in cold water.

ASSEMBLY INSTRUCTIONS

ATTACHING THE LADDER

- 6 Move the Ibiza to shallow water. Attach the ladder in the center of the panel. The AKONA lettering on the ladder steps should be facing the climber.
- Feed both ends of the ladder straps through the gaps on Ibiza jump surface. Pull them through far enough so that the quick link reaches the two loops on the inside of the tube. Have someone hold the ladder in this position while another person goes under
- the tube to connect the ladder.
- 9 Feed the quick link onto the loops of the ladder connection plate and turn the nut until closed and the link is secured.
- Ensure webbing loop is lying flat across the entire width of the quick link as shown. Repeat for other straps.
- 11 Attach the anchor harness following the instructions included with the harness .
- Attach an anchor line (not included) to the swivel ring of the anchor hardness under the Ibiza.

Adjust length of anchor line so that it is approximately 1-2 ft. (0,3-0,7m) longer than the depth of the water. To help prevent flipping of your product in high wind conditions, do not exceed 3 ft (1m) of slack in the anchor line.

NOTE:

More slack will improve anchor holding performance, but too much slack may be sufficient line to allow the Ibiza to stand on edge and flip over in strong winds. For best results, maximize your anchor holding power via more wight or a different type of anchor and minimize your anchor line length.

To anchor for the season, use at least 80-100 lbs. (36-45kg) of anchor weight for most applications. However, on bodies of water where there are high winds, strong currents or large waves may require a heavier or more permanent anchoring system. To anchor for the day, use at least 40-50 lbs. (18-27kg) of anchor weight.

STORAGE AND CLEANING

- Clean the inflatable completely with a mild soap and freshwater or a citrus based cleaner.
- NEVER USE PETROLEUM BASED PRODUCTS OR SOLVENTS FOR CLEANING.
- NEVER USE A POWER WASHER SINCE THE HIGH PRESSURE WATER JET WILL DAMAGE THE SOFT PVC COATING ON THE TUBE BEYOND REPAIR.
- When the inflatable product is not being used, store it in a covered, shaded area. This will help protect it against ultraviolet (UV) rays and extend the life of the product.
- Ultraviolet (UV) rays are very hard on inflatables. To maximize the life
 of your Ibiza, store it out of the sun whenever possible. For additional
 protection, we recommend using 303 protectant, which is a one-step
 product that provides UV protection.
- Product should be completely dry and remain dry while stored.
- Roll the product loosely and place in a container, preferably one that rodents can't chew through.
- Secure against unauthorized or unsupervised use.
- Store in a cool, dry location. Do not store product directly on concrete surface. Place mothballs around stored inflatable to keep mice and insects away.

Rodents, like muskrats, may be attracted to the PVC vinyl of your product. When your product is on the water, maintaining full air pressure during periods of non-use will discourage them from chewing the vinyl.

Another way to ease the problem of nuisance rodents is to remove the temptation by taking the product out of the water at night. You can also make the whole area unattractive to rodents by changing the environment, making the area less hospitable for rodents. Removing any food source from the shoreline can also be a good deterrent. Check with your local DNR for additional guidance or possible restrictions.

REPAIRS

For large holes, tears or seam failures, contact Diversco.

For minor holes or tears:

- Inflate the product and locate the leak by spraying the tube with mild soapy water.
- Determine the hole size and cut a patch 1-2 inches wider than the diameter of the hole. Make sure all corners of the patch are rounded.
- Deflate the product and clean the patch and area around the hole with rubbing alcohol. Let dry.
- READ AND UNDERSTAND THE WARNINGS ON THE GLUE CONTAINER.
- Apply glue to the patch and the area around the hole. Let the glue dry until it is tacky to the touch. (Approximately 1-2 minutes.)
- Lay the product on a flat, hard surface and apply the patch. Working from the center to the outer edge, rub out any air bubbles between the patch and the product.
- Let the patch dry for 24 hours before attempting to inflate the product.

DISCLAIMER

The use of this assumes all risks of any personal injury or death and willfully releases AKONA and/or Diversco Supply Inc. of any and all liabilities. This product is not a life saving device. Do not leave a child unattended while in use. Do not use this product in conditions which are hazardous. Only use this product is you are a competent swimmer. Adult supervision is strongly recommended.

Diversco Supply Inc., doing business as AKONA is in no event liable for any direct, indirect, punitive, incidental, special consequential damages, to property or life, whatsoever arising out of or connected with the use or misuse of our products.

PROP 65 DISCLAIMER

WARNING: This product contains chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information: www.P65Warnings.ca.gov

TERMS OF USE

This product offered to you, conditioned upon your acceptance without modification of the terms, conditions and notices explicitly described or implicitly obtained through normal use of the product. This product may not be used for unlawful purposes, and its use is expressly prohibited under the terms and conditions of its use. The use of this product in any way not in accordance with the terms of use, description, law, or instructions, might be unsafe and lead to injury.

AKONA* EXPRESSLY DISCLAIMS ALL RESPONSIBILITY FOR THE CONSEQUENTIAL DAMAGES OR INCIDENTAL LOSSES CAUSED BY USE OF THIS PRODUCT.

Faults that occur through improper use or damage, abuse, acts of nature, events beyond the control of Diversco Supply Inc./AKONA, repair or alteration by a person other than a person authorized by Divesco Supply Inc./AKONA, or failure to follow instructions for use void any guarantee or warranty.

Additionally, normal wear and tear, including, but not limited to, minor discoloration and scratches are not covered by any guarantee or warranty.

The rights under these terms and conditions, shall only apply to the original purchaser and shall not extend to commercial or communal use

This product is not intended for use by persons (including children) with lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the product by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the product. Keep the product and any cord, or small components, out of reach of children less than 8 years old.

Diversco Supply Inc., reserves the right to change the terms, conditions and notices under which their products are offered.



The word amphibian is ancient Greek and refers to an organism which is able to live two kinds of lives in the two different environments. Frogs live below water and above, much like many of our customers. AKONA makes it easy to experience both land and water. Life's an adventure – AKONA's got the gear.

© All rights reserved.

AKONA 6161 Atlantic Blvd. Norcross, GA, 30071 recgroup@diversco.com 1.800.774.4447

- (a) @akonaadventuregear
- **f** @AKONAAdventureGear

www.akona.com