



Stop! Read this manual carefully before using this product!

Product	Maximum Users	Maximum Weight
Kaos™	Twelve (12)	2400 lbs. (1088 kg)

Contents:

Kaos – (1) Kaos tube, (1) Repair Kit

Watersports Safety Code

Watersports are fun and challenging but involve inherent risks of injury or death. To increase your enjoyment of the sport and to reduce your risks, use common sense and follow these rules:

Before you start:

- Familiarize yourself with all applicable federal, state, and local laws, the risks inherent in the sport, and the proper use of the equipment.
- Know the waterways.
- Use caution and common sense.
- Do not use in recreational swimming pools, within 3,0m (10ft.) of commercial pool edge, or within 4,5m (15ft.) of boats, docks, or other hard obstructions.
- Do not attempt or allow somersaults. Landing on the head or neck can cause serious injury, paralysis or death.
- Never use at night, or in low-light conditions.
- Never use in poor weather conditions with excessive wind, waves or lightning.
- Do not use on dry land.
- Do not use without proper anchoring.
- Do not dive head first or swim under your Kaos™.
- Take extreme care when swimming between the shore and the product. Be cautious of any boat traffic or other obstructions. Ensure all users are capable swimmers and are not excessively fatigued. Do not allow anyone to attempt to swim to or from the product that are not physically able to do so.
- Always ensure that the swimming area around the product is free of submerged logs, rocks and sandbars. Ask about the local water conditions before use.
- Only allow use of the product with proper supervision. Secure the product when not in use to prevent access by any other users.
- Do not jump or dive from this item.
- Do not jump onto this item from any other item.
- Do not use in water where there are sharks or other animals that could pose a threat to humans.
- If product is used indoors, always ensure adequate ceiling height overhead.
- Always remove personal items such as rings, watches or other sharp objects before use.

Your equipment:

- Check all equipment prior to use. Inspect your Rebound™ for missing, defective or worn parts. Never use the product if excessive wear or damage are detected.
- Always check for proper inflation before each use. Temperature and environmental changes can cause changes in tube pressure. Using the product over or under inflated is dangerous and can cause damage to the product, voiding the warranty.
- Always check security of the anchor and all attachments before each use.

It is the owner's responsibility to read the owner's manual and instruct all users in the safe operation of these products. By inflating these products you hereby agree to the Release of Liability, Claim Waiver, and Assumption of Risk Agreement in this manual. Please read this manual prior to inflating and using these products and keep for future reference. As with any action sport, recklessness, inexperience, misuse, or neglect of the equipment may result in serious injury or death.

- Always wear a floatation vest (PFD) as required by the authorities in the area of use.

THE WARNINGS AND PRACTICES SET FORTH ABOVE IN THE WATERSPORTS SAFETY CODE REPRESENT SOME COMMON RISKS ENCOUNTERED BY USERS. THE CODE DOES NOT PURPORT TO COVER ALL INSTANCES OF RISK OR DANGER. PLEASE USE COMMON SENSE AND GOOD JUDGMENT.

Please contact us if you have any questions on the proper selection, function, or safe use of this product.

Warning: This product can only be used with an Aquaglide Runway or Aquaglide Swimstep in order for users to safely gain access to the feature. Failure to use an access pad will render this product unsafe and unusable.

CAUTION

Watersports can be safe and fun for all levels of enthusiasts. The Operator's Manual is presented to enhance your enjoyment of the sport. It is intended to alert you to some of the potentially dangerous conditions that can arise in all watersports. It is the owner's responsibility to read the owner's manual and instruct all users in the safe operation of these products. By inflating these products you hereby agree to the Release of Liability, Claim Waiver, and Assumption of Risk Agreement in the Owner's Manual.

To reduce the risk of injury or death, follow these guidelines:

- Carefully read the product Owner's Manual and follow the instructions.
- Take all reasonable precautions in the use and operation of your trampoline and/or aquapark.
- Teach anyone using your trampoline and/or aquapark about safe guidelines prior to use.
- Know your own limits. Stop when you are tired. Act responsibly. Be in good physical condition and be cautious in your use of this or any other water sports product.
- Periodically check mooring bridle and/or lines to ensure safety. Replace any portion of mooring and/or connection system that shows signs of wear.
- Do not add any hardware or attachments not otherwise supplied by the manufacturer.

THE WARNINGS AND PRACTICES SET FORTH ABOVE REPRESENT SOME COMMON RISKS ENCOUNTERED BY USERS AND DOES NOT PURPORT TO COVER ALL INSTANCES OF RISK OR DANGER. PLEASE USE COMMON SENSE AND GOOD JUDGMENT.







Please contact the dealer or manufacturer of this product if you have any questions about proper selection, function, or safe use of this product.

Made in China




WARNING

USE OF THIS PRODUCT AND PARTICIPATION IN WATERSPORTS INVOLVES INHERENT RISKS OF INJURY OR DEATH.

- This product should never be used by children except under adult supervision.
- Not intended for use by children under 5 years of age.
- This product is not a personal flotation device.
- Always wear a U.S. Coast Guard approved Type III (PFD) vest.
- Never place wrists or feet through handles, straps or rings.
- Do not use in water less than 48" (1.2m) deep or near docks, pilings, swimmers or boats.
- Never swim under the product.
- Do not exceed the manufacturer's recommended number of users for your particular product.
- Do not use while under the influence of alcohol or drugs.
- Read Operator's Manual before use.



NORTH SPORTS, INC.
WHITE SALMON, WA - U.S.A.
STANDARDS: EN 15649: 2012, W.A.S.
PRODUCT: KAOS
MADE IN P.R.C.
DESIGNED IN U.S.A.






No protection against drowning!
Keine Schutz gegen Ertrinken!
Pas de protection contre la noyada!
No protege contra el ahogamiento!
Nessuna protezione contro l'affogamento!
Beschermt niet tegen verdrinken!




Only for swimmers!
Nur für schwimmer!
Seulement pour les nageurs!
Sólo para nadadores!
Solo per i nuotatori!
Alleen voor zwemmers!




North Sports, Inc.
#1 North Shore Dr SE
White Salmon, WA 98672
USA

L: 762 cm (12.6')
W: 762 cm (12.6')
H: 115 cm (3.8')

Compliant with
DIN EN-15649: 2012



WARNING



Prolonged exposure to salt water can damage and/or shorten the expected lifetime of this product. The marine environment includes many damaging elements including corrosion, abrasion and damage from marine life such as barnacles. Regular cleaning and rinsing with fresh water can reduce these risks. A PVC-safe antifouling paint should be used to help protect this product against marine growth. **DAMAGE CAUSED BY EXPOSURE TO SALT WATER IS NOT COVERED BY WARRANTY.**

Assembly

- 1) Locate a flat, dry area with access to electrical outlet or extension cord.
- 2) Unroll and place the Kaos™ on the ground and locate the outer valve (see fig 1). Remove valve cover and push valve plunger in. Twist the valve stem 90 degrees to open or close the 1-Way valve feature.
- 3) Using a high output inflator/deflator place the inflation hose with proper adaptor into the valve. Inflate to 0.8 psi (0,055 bar) where tube is firm and tight. Check for proper air pressure using a manometer. Inflation times can vary by inflator, but the tube should be firm and tight when completely inflated. In hot weather, be sure to leave room for air expansion. DO NOT OVER-FILL. Close the valve and secure valve cap.

WARNING: Do not use an air compressor to inflate tube. Air compressors are designed for high pressure inflation and can cause tube to burst if over-inflated. The inflator/deflator described above cannot over-inflate the tube.

- 4) Next locate and inflate the inner valve (see fig 1). Which is underneath the product. You will need to lift the product in order to inflate. Inflate to 0.03 (0,002 bar). It should be approximately 70% full.

WARNING: If the inner valve chamber is under-deflated, the product can become very dangerous by creating a launching effect. Please make sure your product has adequate air pressure to ensure people are not launched in the air.

- 5) Congratulations! You are now ready to place your Kaos™ in the water. To launch your Kaos™, make sure to have at least 4-6 people evenly spaced around the bouncer to help carry the Kaos™ into the water.

NEVER DRAG YOUR KAOS! YOU MUST LIFT AND SET TO AVOID ANY ACCIDENTAL TEARING ON SHARP OBJECTS. We recommend using a carpet or tarp if you are setting up the product in a dangerous area.

- 6) Optional: if you would like to connect your Kaos to other Aquaglide products, follow the Vario-Lock cinch straps provided on the right side of this page.

Figure 1



How to connect your Aquaglide Products using the Vario-Lock cinch strap (when applicable)

- 1) Your product may or may not come with the Vario-Lock cinch straps already connected to all the appropriate D-rings. If they are not pre-installed please follow steps 2-3 to properly secure them to the appropriate D-ring.



Fig A: Running loop of Vario-Lock cinch strap through D-ring

- 2) Run loop end of Vario-Lock cinch strap through D-ring on product (Fig. A)

- 3) Take tag end of Vario-Lock cinch strap and thread through loop (Fig. B)



Fig B: Working tag end through loop. It should look like this once tag end is through the loop

- 4) Run tag end of Vario-Lock cinch strap through D-ring on other product to be attached (Fig. C)

- 5) Run tag end through cam and tighten until the two products are securely connected (Fig. C)

- 6) Run tag end through cam and tighten until the two products are securely connected (Fig. C)



Fig C: Running tag end through D-ring and back through cam to cinch tight

*To undo Vario-Lock cinch strap, simply press cam buckle and pull strap through backside of cam.




Figure 1a

Anchoring

NOTE: Take a moment to locate the anchoring rings underneath your Kaos™. The Kaos™ has 2 anchor rings on the underside of the tube. Attach anchor line to at least 1 ring. We suggest using 2 rings with a 2-way bridle (not included) for long term mooring.

IMPORTANT: Proper anchoring is essential to the safety and performance of your product. Due to the wide variety of conditions, we advise using a professional skilled in mooring and anchoring, and experienced with local conditions. If improperly anchored, the product can move and/or float away. Aquaglide, Inc. is not responsible for any damage, injuries or losses due to improper anchoring.

Here are some general guidelines for anchoring your product. These guidelines are not intended to replace the need for professional installation.

- 1) Choose a location for your Kaos™ bouncer and/or aquapark. Place the product in at least 8 ft. of water depth and in an area protected from the wind and boat traffic. Review relevant rules and restrictions with your local authorities.
- 2) Carefully check area under the bouncer and/or aquapark for sharp or dangerous objects (i.e. rocks or stumps).
- 3) Keep a safe distance from docks, boats, boat lifts, and any other structures. **DO NOT** tie the product to a dock!
- 4) Anchors and anchor line are sold separately. Ground screws or heavier anchors (300 lbs. or more) should be used when on large or windy bodies of water.
- 5) Attach anchor line securely to the anchor. Use a buoy tied to the other end of the rope to easily locate your anchor.
- 6) When the product is in place, remove the buoy and tie or shackle the anchor line to the anchor rings underneath the product. Allow **AT LEAST** several feet of slack in the line before securing the line. This will allow the product to move in wind or waves without displacing your anchor.
- 7) If strong winds or storms are expected, it is best to remove the product from the water and deflate it. You can also move it closer to shore and secure it with lines.

Operation

- 1) This item is a water bouncer. Users bounce near the center of the item. This item must be used with at least one Aquaglide boarding platform.
- 2) When connecting multiple items, use only Aquaglide Vario-Lock cinch straps and connecting rings according to the instructions provided. Make sure that the connection is tight and that there is **NO GAP** greater than 25mm (~3/4") between items. **IMPORTANT:** Failure to connect these items properly may result in injury or death.

Care and Maintenance

- 1) While your product has been initially treated with UV protectant, long-term exposure to sunlight will damage the product. Regularly apply a UV protectant to the exposed surface of the tube to ensure the life of your product. We recommend using **ONLY** INDIKON POLY GUARD UV for this purpose. Seasonal application while the product is in use is recommended. **NOT DOING SO OVER LONG TERM WILL VOID THE WARRANTY.** POLY GUARD UV is available at most watersports dealers, or online at <http://www.aquaglide.com/product-category/accessories/maintenance/>.
- 2) **WARNING:** Certain products, especially petroleum-based solvents, cleaners and protectants such as ArmorAll can damage the product and use of these products will void the warranty.
- 3) **WARNING:** Use of a high-pressure washer will damage the product and void the warranty. To clean, use a soft bristle brush with mild soap and fresh water. INDIKON MAXI CLEAN PVC can be used to thoroughly clean the product before storage.
- 4) Check the inflation of your tube often. Check for proper air pressure using a manometer. It may appear to have lost air early in the morning, but will expand once the sun warms it. Maximum expansion will occur in the heat of the day. Under-inflation can cause excessive wear. Proper inflation is important as this will discourage marine animals from chewing and prevent damage from wear.

Storage

- 1) Before storing, place the product on a clean, level area. Clean with mild soap and water and allow to dry completely. Apply POLY GUARD UV to the surface of all tubes before deflating.
- 2) Remove all attachments and store in a sealed water-proof container (i.e. a plastic covered box or bin).
- 3) Remove **ALL** of the air from the tube using the deflation end of the high output inflator/deflator.
- 4) Fold the deflated tube in thirds then flat-fold or roll loosely.
- 5) Store the product out of direct sunlight and protected from the environment in a clean, dry location. It is best to store inside a container with moth balls to prevent damage from rodents. **NEVER** store uncovered, in a damp location, or on concrete surface! **NEVER** store at temperatures below 40 degrees F.



Aquaglide

Commercial Repair Instructions

INSTRUCTIONS

Leaks must be patched with the item completely deflated and patches must be allowed to cure for 12 hours minimum. Curing for 24 hours is highly recommended. In most cases you will need enough room to inflate the product for inspection.

Following these instructions and using patch material similar to the original material is the best way to ensure the strength and durability of your Aquaglide product.

WORK SPACE AND TOOLS

1. Take care to position yourself in a clean, dry area with good ventilation. For proper curing of adhesives temperature should remain above 50 degrees F and relative humidity below 60%.
2. Repair Kit Contents: PVC patch material, MEK cleaner, 220 grit sandpaper, PVC glue, shop towel, china marker, instructions.
3. Additional items that may be needed: Air pump, sharp scissors and / or razor knife, dish washing liquid, water, small bowl or spray bottle, rubbing alcohol, clamps, wood for clamp use (see images), Tear-Aid™ Patch material,

LOCATE LEAK(S)

1. If there is a problem with air leaks, you will need to locate the leak(s) first.
2. Inflate your Aquaglide product fully. Some small leaks can close themselves at lower air pressures, so it is best to maintain full pressure by re-inflating periodically while checking for leaks.
3. Use a soapy water solution (50% / 50% dish soap & water) and a cloth to check for leaks. Work slowly around the product spraying or swabbing-on soapy water solution. Look for growing bubbles, which indicate a leak.
4. Once a leak is confirmed, dry the area well. Mark leak with china marker and prepare to patch.

PATCHING

1. Deflate your Aquaglide product completely.
2. Carefully cut PVC patch material to size using sharp scissors or razor knife.
 - a. Ideally you want to have at least 1-2" in all directions around any air leak. This means a minimum patch size of 2" x 2" for a pinhole leak. The larger, the better.
 - b. Square patches with rounded corners are usually best as this reduces the risk of peeling.
3. Dry-fit the patch over the area to be repaired to ensure good fit and coverage.
4. Use clean 220 grit sand paper provided to rough up the surface to be patched as well as the back of the patch material.
5. Use MEK (provided), and a fresh cloth to clean the sanded areas, removing all debris.
6. Dry-fit the patch again and use china marker (provided) to carefully outline where the patch will be located.
7. Use the glue (provided). Try to work neatly and quickly.
 - a. Apply a thin, even layer of glue to the repair area making sure to cover the area completely. Stay inside the china marker outline.
 - b. Apply a thin, even layer of glue to the back of the patch making sure to cover the area completely.
 - c. Allow glue to cure for 2-3 minutes or until dry to touch.
 - d. Starting at one corner, carefully align the patch over the repair area using the china marker outline as a guide. Once the 2 surfaces touch, the bond will be immediate, so take care.
 - e. Starting at one corner and working outward, carefully apply the patch to the repair area using very firm pressure.
 - f. Using a rubberized roller or similar device, rub the entire patch area and the edges of the patch using very firm pressure.
 - g. Allow to cure for 12 hours minimum using clamps and wood to apply pressure.
 - h. Remove clamps and wood then Inflate and check pressure after 24 hours.



NOTICE! - Release of Liability, Claim Waiver, and Assumption of Risk Agreement

By opening and assembling this product, you are agreeing (1) to be bound to the terms set forth below and (2) to require anyone using this product to be bound by such terms. If you are unwilling to be bound by these terms, return this product (before use) for a full refund.

ASSUMPTION OF RISK: Use of this product and any of its components involves certain inherent risks, dangers, and hazards which can result in serious personal injury and death. In using the product, you freely agree to assume and accept any and all known and unknown risks of injury while using this equipment. The risks inherent in the sport can be greatly reduced by abiding by the Warning Guidelines listed in this Owner's Manual and by using common sense.

RELEASE AND WAIVER OF CLAIMS AGREEMENT: In consideration of the sale of the product to you, you hereby agree to the fullest extent permitted by law as follows:

TO WAIVE ANY AND ALL CLAIMS that you have or may in the future have against North Sports, Inc., its distributors and dealers, resulting from use of this product and any of its components.

TO RELEASE North Sports, Inc. from any and all liability for any loss, damage, injury, or expense that you or any users of this product may suffer, or that your next of kin may suffer, as a result of the use of this product, due to any cause whatsoever, including negligence or breach of contract on the part of North Sports, Inc. in the design or manufacture of this product and any of its components.

ARBITRATION: In further consideration of the sale to you of this product and any of its components, you hereby agree to submit to binding arbitration any and all claims which you believe you may have against North Sports, Inc. arising from the use of any North Sports, Inc. and Aquaglide® equipment or products. The arbitration shall be pursuant to the rules of the American Arbitration Association. Arbitration shall be commenced within (1) year from the date on which any alleged claim first arose. Further, the arbitration shall be held in White Salmon, Washington unless otherwise mutually agreed to by all parties. The submission to the American Arbitration Association shall be unlimited and the arbitration award may be enforced by any Court of competent jurisdiction.

BINDING EFFECT OF AGREEMENT: In the event of your death or incapacity, this Agreement shall be effective and binding upon your heirs, next of kin, executors, administrators, assigns, and representatives.

ENTIRE AGREEMENT: In entering into this Agreement, you are not relying upon any oral or written representations other than what is set forth in this agreement and the North Sports, Inc. and Aquaglide® Owner's Manual.

Warranty | Returns | Service Policy

Aquaglide® warrants this product to be free of defects in material or workmanship to the original purchaser for a period of three (3) years from date of purchase. This warranty is subject to the following limitations:

1. Warranty is valid only with dated proof of purchase in the form of the original invoice.
2. Warranty is valid only when the product is used for normal recreational or commercial activities, and does not cover damage, or any issues resulting from misuse, excessive use, or lack of normal maintenance.
3. Aquaglide® will make the final warranty determination which may require inspection and/or photos of the product which clearly show defect(s). We may require the product be sent to another location of our choice, freight prepaid, or photos and other proof of claim be sent by email to support@aquaglide.com.
4. If a product is deemed to be defective by Aquaglide®, the warranty covers the repair or replacement of the defective product only, at Aquaglide's® discretion. Aquaglide® will not be responsible for any costs, losses, or damages incurred as a result of loss of use of product, or any other claims of any kind.
5. This warranty does not cover damage caused by misuse, abuse, neglect, or normal wear and tear, including, but not limited to, punctures; damage caused

by dragging the product over the ground; damage due to excessive sun exposure or seam failure due to over-inflation in the sun; damage caused by improper handling, or improper storage; damage caused by marine growth or other marine animals; damage caused by use in waves or shore break; or damage caused by anything other than defects in materials and workmanship.

6. Warranty coverage will be pro-rated at the discretion of Aquaglide® in a reasonable manner, based on the issue(s) at hand and the age and condition of the item. Typical pro rata coverage scale (may vary):
 - ≤6 Months Replacement
 - ≤1 Year Repair or 75% - 100% of replacement cost
 - ≤2 Years Repair or 50% - 75% of replacement cost
 - ≤3 Years Repair or 25% - 50% of replacement cost
7. This warranty is voided if any unauthorized repair, change, or modification has been made to any part of the product without the express written authorization of Aquaglide®.
8. The warranty for any product which has been repaired or replaced under this warranty is valid from the date of the original purchase only.
9. Any warranty claims must be accompanied by the original purchase receipt. The name of the retailer and date of purchase must be clear and legible.
10. There are no warranties which extend beyond the

warranty specified here.

Returns and Service Policy

Product can be returned only if a return authorization number (RA) is given by Aquaglide® in advance. The RA number must be on the outside of the package or it will not be accepted at our warehouse. Freight on the returned product must be prepaid or it will not be accepted. Upon receipt, Aquaglide® will make a determination within (30) days. If the product is covered under warranty it will be returned to the customer at the expense of North Sports, Inc. after repairs can be made. If not, the customer will receive a quote for repair and/ or replacement as well as any necessary cleaning and shipping charges. The customer will have 30 days to accept the quotation. At the end of 30 days, or upon refusal of the quote, Aquaglide® will return the product in the condition in which it was received at the customer's expense. The customer agrees to authorize North Sports, Inc. to charge the customer's credit card for any costs not covered under the terms and conditions of the Aquaglide® Warranty.

Serial Number

All Aquaglide products are marked with a serial number near the main inflation valve (#1). The serial number may be stamped into the PVC directly around the valve, or it may be visible on a welded plate near the valve. Please include this number when you contact Aquaglide®, or your dealer, with any warranty claim.